Today

- R-C Circuits cont
- Diodes
- Representing information



Analog representation: the precise voltage matters.

- Suppose we observed voltage v on a wire (e.g., an output from an accelerometer)
- The encoded quantity is some function of that voltage:

$$acceleration = f(v)$$

The simplest form assumes a linear relationship:

$$acceleration = \alpha v + \beta$$

- Digital representation: the value to be represented is binary – i.e., true or false
- For example, a bit b is:

$$b = \begin{cases} \text{true} & v > 2.5 \text{ Volts} \\ \text{false} & \text{otherwise} \end{cases}$$

We typically use the shorthand:


$$0 = false$$

$$1 = true$$

Computing In Binary (i.e., Logic)

What is the Gate?

Logical Symbol:




- Algebraic Notation:
- Truth Table:

Α	В
0	
1	

The NOT Gate

Logical Symbol:



- Algebraic Notation: $B = \overline{A}$
- Truth Table:

А	В
0	1
1	0

And This Gate?

• Logical Symbol:


Algebraic Notation: C = ?

• Truth Table:

Α	В	C
0	0	
0	1	
1	0	
1	1	

The "AND" Gate

• Logical Symbol:



Algebraic Notation: C = A*B = AB

• Truth Table:


Α	В	С
0	0	0
0	1	0
1	0	0
1	1	1

Andrew H. Fagg: Embedded Real-

Time Systems: Logic

And This Gate?

Logical Symbol:




Algebraic Notation: C = ?

• Truth Table:

Α	В	С
0	0	
0	1	
1	0	
1	1	

The "OR" Gate

Logical Symbol:




Algebraic Notation: C = A+B

• Truth Table:

Α	В	С
0	0	0
0	1	1
1	0	1
1	1	1

Exclusive OR ("XOR") Gates

• Logical Symbol:




Algebraic Notation: C = A⊕B

Truth Table:

Α	В	C
0	0	
0	1	
1	0	
1	1	

Exclusive OR ("XOR") Gates

• Logical Symbol:



Algebraic Notation: C = A⊕B

Truth Table:


Α	В	C
0	0	0
0	1	1
1	0	1
1	1	0

2-Input Multiplexer

A multiplexer is a device that selects between two input lines



- S is the selection signal (also an input)
- C is a copy of A if S=0
- C is a copy of B if S=1




2-Input Multiplexer

A multiplexer is a device that selects between two input lines



- S is the selection signal (also an input)
- C is a copy of A if S=0
- C is a copy of B if S=1




2-Input Multiplexer

A multiplexer is a device that selects between two input lines




- S is the selection signal (also an input)
- C is a copy of A if S=0
- C is a copy of B if S=1



N-Input Multiplexer

Suppose we want to select from between N different inputs.

 This requires more than one select line. How many?




N-Input Multiplexer

How many select lines?

•
$$M = log_2 N$$
 or

•
$$N = 2^{M}$$

What would the N=8 implementation look like?



Back to Binary...

With a binary digit, we can only represent two different values...

Back to Binary...

With a binary digit, we can only represent two different values...

As in the decimal number system, we introduce multiple digits...

Binary Encoding

How do we convert from binary to decimal in general?

B2	B1	B0	decimal
0	0	0	0
0	0	1	1
0	1	0	2
0	1	1	3
1	0	0	4
1	0	1	5
1	1	0	6
1	1	1	7

Binary to Decimal Conversion

$$value = B_0 + B_1 * 2^1 + B_2 * 2^2 + B_3 * 2^3 + \dots$$

$$value = \sum_{i=0}^{N-1} B_i * 2^i$$

How do we convert from decimal to binary?

Decimal to Binary Conversion

```
int value;
For each i: B[i] = 0
for(i = 0; value > 0; ++i) {
 B[i] = remainder of: value/2;
 value = value/2;
```

• Circuit example...

Consider the following binary numbers:

00100110

00101011

How do we add these numbers?

0010011000110

0010011000110

And we have a carry now!

00100110

00101011



001

And we have a carry again!

00100110 00101011 \frac{1}{4} 0001 and again!

00100110 00110 00110 00110

00100110 00101011 \ \ 01010001

Behaves just like addition in decimal, but:

 We carry to the next digit any time the sum of the digits is 2 (decimal) or greater

Negative Numbers

So far we have only talked about representing non-negative integers

 What can we add to our binary representation that will allow this?

One possibility:

- Add an extra bit that indicates the sign of the number
- We call this the "sign-magnitude" representation

+12 0 0001100

+12

0 0001100

-12

1 0001100

+12

0 0001100

-12

1 0001100

What is the problem with this approach?

What is the problem with this approach?

 Some of the arithmetic operators that we have already developed do not do the right thing

Operator problems:

 For example, we have already discussed a counter (that implements an 'increment' operation)


1 0001100

Operator problems:

Operator problems:


-12 1 0 0 0 1 1 0 0 Increment
1 0 0 0 1 1 0 1


Operator problems:




An alternative:

- When taking the additive inverse of a number, invert all of the individual bits
- The leftmost bit still determines the sign of the number







What problems still exist?

What problems still exist?

 We have two distinct representations of 'zero':


0 000000


1 1111111

What problems still exist?

 We can't directly add a positive and a negative number:

```
12 0 0001100
```






An alternative:

(a little intuition first)

0




An alternative:

(a little intuition first)

An alternative:

(a little intuition first)



A few more numbers:


3	0	0	0	0	0	0	1	1
2	0	0	0	0	0	0	1	0
1	0	0	0	0	0	0	0	1
0	0	0	0	0	0	0	0	0
-1	1	1	1	1	1	1	1	1
-2	1	1	1	1	1	1	1	0
-3	1	1	1	1	1	1	0	1

In general, how do we take the additive inverse of a binary number?

In general, how do we take the additive inverse of a binary number?

Invert each bit and then add '1'

Invert each bit and then add '1'




Now: let's try adding a positive and a negative number:

12 0 0 0 0 1 1 0 0


- -

-5 1 1 1 1 1 1 0 1 1

Now: let's try adding a positive and a negative number:



Now: let's try adding a positive and a negative number:



Two's complement is used for integer representation in today's processors

Two's complement is used for integer representation in today's processors

One oddity: we can represent one more negative number than we can positive numbers

Implementing Subtraction

How do we implement a 'subtraction' operator?

(e.g., A - B)

Implementing Subtraction

How do we implement a 'subtraction' operator?

(e.g., A-B)

- Take the 2s complement of B
- Then add this number to A

Other Useful Number Systems

You already know:

- Decimal base 10
- Binary base 2

Other Useful Number Systems

You already know:

- Decimal base 10
- Binary base 2

But it is common to also see:

- Octal base 8
- Hexadecimal base 16

Other Number Systems

Decimal	Binary	Octal	Hex
0	0000	0	0
1	0001	1	1
2	0010	2	2
3	0011	3	3
4	0100	4	4
5	0101	5	5
6	0110	6	6
7	0111	7	7

Decimal	Binary	Octal	Hex
8	1000	10	8
9	1001	11	9
10	1010	12	А
11	1011	13	В
12	1100	14	С
13	1101	15	D
14	1110	16	E
15	1111	17	F


What is the hex equivalent of:

011000111001001

What is the hex equivalent of:

Partition the binary digits into groups of four – starting from the right-hand-side

What is the hex equivalent of:



Convert the individual groups

In C notation (the programming language), we will write:

0x31C9


What is the octal equivalent of:

011000111001001

What is the octal equivalent of:

Partition the binary digits into groups of three – starting from the right-hand-side

What is the octal equivalent of:



Convert the individual groups

In C notation (the programming language), we will write:

030711

Octal or Hex to Binary

How do we perform this type of conversion?

Octal or Hex to Binary

How do we perform this type of conversion?

- For each octal or hex digit, convert to the binary equivalent (3 or 4 binary digits, respectively)
- Append the binary digits together

Binary Notation in C

How would we write a binary constant in C?

Binary Notation in C

How would we write a binary constant in C?

0b011000111001001